



chorus™

Remote + We-Connect™ Pairing Instructions

Unpair Chorus (at the end of a Chorus training session):

1. Unpair Chorus from within the We-Connect app.
2. Remove Chorus from the Bluetooth® device settings on your phone or tablet.

Pair Chorus to remote (at the beginning of a Chorus training session):

1. Press and hold the control button on Chorus for 10 seconds (Chorus will pulse twice – continue holding the button until the light flashes 3 times).
2. Press and hold the “+” button on the remote until Chorus pairs to the remote (Chorus will pulse 3 times once paired).
3. Press any button on the remote except for the function button (top button with the wave) to feel Chorus respond. If Chorus responds, the remote is successfully paired to Chorus.

Activate Squeeze Control:

1. To activate Squeeze Control on the Squeeze Remote, press and release the function button. The light on the remote will flash 3 times.
2. Squeeze and release the remote to feel changes in the strength of the vibrations. Repeat as desired.
3. To stop using Squeeze Control, press and release the function button. The light on the remote will flash 2 times.

Pair Chorus to We-Connect:

1. Press and hold the control button on Chorus for 5 seconds (until it pulses twice).
2. You can then begin the pairing process within the We-Connect app.

Note: You cannot pair Chorus to the We-Connect app without the Squeeze Remote. Chorus uses AnkorLink™ technology to create a stable connection between Chorus and the app, and the Squeeze Remote is the anchor between this connection. Make sure you keep the Squeeze Remote close by whenever you use We-Connect.

